

Message

From: Moore, Gary [/O=EXCHANGELABS/OU=EXCHANGE ADMINISTRATIVE GROUP (FYDIBOHF23SPDLT)/CN=RECIPIENTS/CN=D9494EB3B37241B09CE3BDEAFF4C557A-MOORE, GARY]
Sent: 10/1/2018 3:46:37 PM
To: Powell, Greg [Powell.Greg@epa.gov]
Subject: F.J. Doyle Salvage Stie

Greg:

Can you get this to the right person if not you?

We are going to be demolishing a building at a former PCB dismantling facility. They did do cutting and grinding on the transformers. It is a metal building with wood structures.

We are going to do the following: Asbestos Inspection – Required for Reno/Demo

We are planning on doing PCB wipe samples to include analysis for Aroclor 1268 (Galbestos?)

We are going to sample for lead paint

Question: Is there a need to include Dioxins/Furans for the wipe samples?

Thanks

Gary W. Moore (6SF-ER)
Federal On-Scene Coordinator
U.S EPA Region 6
1445 Ross Ave, Suite 1200
Dallas, TX 75202-2733
Cell: 214.789.1627
moore.gary@epa.gov